

HI 6500 Programmer's Quick Reference

The Programmer's Quick Reference guide is intended to be a helpful and efficient reference tool for power users and technical personnel when interfacing with this Hardy product. It is not designed to replace the User's Guide.

Users Guide:

<https://www.hardysolutions.com/Content/Downloads/>

<Manual/92d7e887-95df-4ad1-867e-4199c63dfc6e.pdf>

Online Unit:

<http://hi6500.hardysolutions.com/>


Default IP Address:

192.168.0.100

NOTE: Units have an internal webpage to use.

Input Table:

- EIP_HI6500:I	{ ... }		_0102:
- EIP_HI6500:I.ConnectionFaulted	1	Decimal	BOOL
+ EIP_HI6500:I.Command	16#0000_0066	Hex	DINT
+ EIP_HI6500:I.Command_Status	16#0000_0003	Hex	DINT
+ EIP_HI6500:I.Parameter_ID	0	Decimal	DINT
+ EIP_HI6500:I.Parameter_Value	0	Decimal	DINT
+ EIP_HI6500:I.Unit_Status	16#0000_0000	Hex	DINT
- EIP_HI6500:I.Net_Weight	60.19476	Float	REAL
- EIP_HI6500:I.Gross_Weight	15.0	Float	REAL
+ EIP_HI6500:I.Read_1	0	Decimal	DINT
+ EIP_HI6500:I.Read_2	0	Decimal	DINT
+ EIP_HI6500:I.Read_3	0	Decimal	DINT
+ EIP_HI6500:I.Read_4	0	Decimal	DINT
+ EIP_HI6500:I.Read_5	0	Decimal	DINT



Output Table:

- EIP_HI6500:O	{ ... }		_0102:
+ EIP_HI6500:O.Command	16#0000_0066	Hex	DINT
+ EIP_HI6500:O.status_data	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_Value	0	Decimal	DINT
+ EIP_HI6500:O.Reserved1	0	Decimal	DINT
+ EIP_HI6500:O.Reserved2	0	Decimal	DINT
+ EIP_HI6500:O.Reserved3	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID_1	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID_2	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID_3	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID_4	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID_5	0	Decimal	DINT

Commands:

Command number	Command
0	Read Parameter
1	Zero Cmd
2	Tare Cmd
4	Write Non-Volatile Cmd
5	Print Cmd
6	Weigh Sample Cmd
0x64 (100 dec)	Cal Low Cmd
0x65 (101 dec)	Cal High Cmd
0x66 (102 dec)	C2 Cal Cmd
0x1000 (4096 dec)	Write Integer Cmd
0x1001 (4097 dec)	Write Float Cmd

COMMANDS

E.G. A C2 Cal command through the output table:

- EIP_HI6500:O	{ ... }		_0102:Hardy...
+ EIP_HI6500:O.Command	16#0000_0066	Hex	DINT

COMMAND BEING GIVEN

Each command will echo in the “Command” tag of the input table once it has been run and will have its status returned into the “Command Status” tag.

Example: A C2 Cal command being echoed back (66) and failure status due to motion (3).

- EIP_HI6500:I	{ ... }	_0102:H
- EIP_HI6500:I.ConnectionFaulted	1	Decimal BOOL
+ EIP_HI6500:I.Command	16#0000_0066	Hex DINT
+ EIP_HI6500:I.Command_Status	16#0000_0003	Hex DINT

COMMAND ECHO

Status returns will vary. A complete list of status returns is listed in the Users Guide (starting on page 38).

0x66 (102 decimal): C2 CAL CMD. Write a 0x66 hex to the command register to perform a C2 calibration.

- Calibration_Fail 1
- Calibration_Fail_Motion 3
- Calibration_Fail_AdC_Error 4
- Calibration_Fail_Noc2 5
- Calibration_Fail_C2capeq 6
- Calibration_Fail_C2clones 7
- During a C2 Cal Command: Code 2 indicates "calibration in progress".

COMMAND STATUSES

General Tip:

“0x” and “16#” are used to signify a Hex value.

Hexadecimal commands and statuses are common however a decimal value can also be used.

E.G. A hex command of 0x66 would be equal to a decimal value of 102.

+ EIP_HI6500:O.Command	16#0000_0066	Hex	DINT
------------------------	--------------	-----	------


COMMANDS IN HEX AND DECIMAL

+ EIP_HI6500:O.Command	102	Decimal	DINT
------------------------	-----	---------	------

Example: A C2 Calibrate command of “0x66” would be entered as “16#0000_0066”

Parameters:

Parameters can be changed with the built-in webpage or the AOP by double clicking on the unit in the controller organizer of the program. The ID# 25 must be “Enabled” to use this feature.



Configuration Parameters						
General Connection Module Info Configuration Parameters Internet Protocol Port Configuration						
Group: <All Parameters>						
ID	Name	Value	Units	Style	Description	
25	Enable_Disable	Disable			Enables/Disables the module.	
26	Unit	lb			Units set for the module.	
27	Grads	0 = 1			Grads/Display 1.	
28	Motion Tolerance	10.0		Float	Enter Motion Tolerance.	
29	Decimal Point	2			Select Decimal Point.	
30	Scale Capacity	999999.0		Float	Enter Scale Capacity.	
31	Loadcell Sensitivity	3.0 mV/V		Float	Select Loadcell Sensitivity.	
32	Cal Motion Tolerance	10.0		Float	Enter Calibration Tolerance.	
33	Ref Weight	0.0		Float	Enter Reference Weight.	
34	Gravity Correction	1.001159		Float	Enter Gravity Correction.	
35	Span Weight	1000.0		Float	Enter Span Weight.	
36	Waversaver	1.0 Hz			Waversaver Frequency.	
37	Num Averages	10		Decimal	Enter the number of averages.	
38	Count Enable	Disable			To enable Counting.	
39	Unit Weight	0.0	Float		Enter Unit Weight.	

Insert Factory Defaults

Information: The values displayed here are from the Configuration Tag. These values are stored in the controller and are automatically sent to the module when changes are applied or a connection is established.

Status: Offline


OK Cancel Apply Help

AOP

Parameter Message Tip:

Parameters can be changed in the “C” (Configuration) table and a Module Reconfigure type MSG instruction can be executed to write the “C” parameters to the unit.

Example:



Reading Parameters Manually:

A command of “0” is a read parameter command.

The parameter ID must be chosen to read a parameter.

The parameter IDs are located in the manual. (Starting on page 115)

Menu	SubMenu	Parameter Name	Param ID
Filter	(menu items)	WAVERSAVER	0x2081
Filter	(menu items)	Num Averages	0x2082
Filter (XP only)	(menu items)	Motion Threshold	0x2101

PARAMETER VALUES

E.G. A read parameter command to read the number of averages (0x2082)

+ EIP_HI6500:O.Command	16#0000_0000	Hex	DINT
+ EIP_HI6500:O.status_data	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID	16#0000_2082	Hex	DINT

READING A PARAMETER

The command will echo and the parameter value will appear in the input table of the PLC.

- EIP_HI6500:I	{ ... }	_0102	
- EIP_HI6500:I.ConnectionFaulted	1	Decimal	BOOL
+ EIP_HI6500:I.Command	16#0000_0000	Hex	DINT
+ EIP_HI6500:I.Command_Status	16#0000_0000	Hex	DINT
+ EIP_HI6500:I.Parameter_ID	16#0000_2082	Hex	DINT
+ EIP_HI6500:I.Parameter_Value	10	Decimal	DINT

THE READ PARAMETER ECHO

Writing Parameters Manually:

A command of “1000” is the write integer command to write an integer value to an integer type parameter.

E.G. Writing a value of 50 to the number of averages parameter.

- EIP_HI6500:O	{ ... }	_0102	
+ EIP_HI6500:O.Command	16#0000_1000	Hex	DINT
+ EIP_HI6500:O.status_data	0	Decimal	DINT
+ EIP_HI6500:O.Parameter_ID	16#0000_2082	Hex	DINT
+ EIP_HI6500:O.Parameter_Value	50	Decimal	DINT

WRITING A PARAMETER

The input table will echo and the written data will appear.

- EIP_HI6500:I	{ ... }	_0102	
- EIP_HI6500:I.ConnectionFaulted	0	Decimal	BOOL
+ EIP_HI6500:I.Command	16#0000_1000	Hex	DINT
+ EIP_HI6500:I.Command_Status	16#0000_0000	Hex	DINT
+ EIP_HI6500:I.Parameter_ID	16#0000_2082	Hex	DINT
+ EIP_HI6500:I.Parameter_Value	50	Decimal	DINT

THE WRITE PARAMETER ECHO

Using the USB

Saving Parameters to a USB drive is easy using the display or webpage.

The parameters will be a small text file inside an HI6500 folder on the USB.

NOTE: USBs vary. If the read or write does not appear to function, try another USB.

Restoring Parameters:

Upon bootup, the HI6500 will search a connected USB for a restore.txt file in an HI 6500 folder.

It will restore the values that are in the restore.txt file.

The restore.txt file is the same format as the params.txt file.


A params.txt file can be renamed restore.txt to create a default parameter restoration file.

For example, a commonly restored parameter is the IP address.



In this example, we have deleted the other parameters and just left the IP address.

NOTE: The first line is ignored. Always paste a firmware revision line *then* the desired restore information.





USB PARAMS TEXT FILE

00007985 Firmware Revision=HI6500 2.1.4.0

00003101 Fixed IP=192.168.0.100

Save the file as restore.txt in the HI6500 folder of the USB.



USB RESTORE TEXT FILE

If this file is saved in the HI6500 folder, then every time the USB is installed and power is cycled, the fixed IP will change to 192.168.0.100.